

Zünd Quickstart Guide

On the Zünd

- Place the cutting mat in a way that it touches the aluminium stop on the right and is aligned with the front edge of the table*
- Align your material with the pencil marks on the mat
- Press the ONLINE-KEY and you're DONE!

On the computer

- Open Rhino
- Import your DXF-File and place your geometry inside the (green) cutting area

(cutting only)

- Enter ZORG_CUT in the Rhino command-line
- - Select all the lines you want to cut (press ENTER when done)
- - Select TOOL**, VACUUM_WIDTH***, SPEED
- - Press ENTER
- - Confirm with ENTER, Y or RMB if your settings are OK

(engraving only -> works only with the knife tool!)

- Enter ZORG_ENGRAVE in the Rhino command-line
- - Select MATERIAL_THICKNESS, ENGRAVING_DEPTH, VACUUM_WIDTH, SPEED

WANNA CHANGE THE KNIFE? ASK THE WORKSHOP STAFF - YOU'RE NOT ALLOWED TO DO IT YOURSELF!!

* No tape necessary!

** Tools: left -> knife, right -> oscillating knife, pen

*** Width in of your material (Y-Axis only)
